



Instructions:

- 1) Cut along solid lines
- 2) Fold up along dotted lines, making a 45 degree angle
- 3) Put a tack through the center hole into a wooden rod.

